

MTCE-10R-NT　*MTCE-10T-NT*

1.1　Appearance and terminal






3.1 Ambient temperature

3.2 Installation site

3.3 Installation method

Wiring Requirements


4.1 Terminal introduction



⏚	

Display Area

4.2 Wiring



5.1 Power-supply Specification

5.2 Performance Specification

≤ ≤

×

Â Âº

© 00µ

Æ ,

_ _ _
